RESIDENTIAL RIBLINE® ROOFING RAKING INTERNAL GUTTER

MIN

HEM TO FLASHING

FDGF

UNDERLAY

ROOFING INDUSTRIES

RAFTFR

TOP PLATE

GUTTER DEPTH

ROOF PITCH

< 12°

12° or greater

'RIBLINE'

UNDERLAY

80

MIN

Detail Number: RI-RRR028A

Date drawn: 07/07/2017

Scale: 1:5@ A4

NOTES:

DESIGNER TO ENSURE DURABILITY OF FLASHING MATERIAL:

- SITUATION I: IN LOW. MEDIUM OR HIGH WIND ZONES. WHERE ROOF PITCH IS 10° OR GREATER
- 2 SITUATION 2: FOR ALL ROOF PITCHES IN VERY HIGH AND EXTRA HIGH WIND ZONES, FOR ALL WIND ZONES WHERE ROOF PITCH IS IESS THAN LO°
- 3. SITUATION 3: FOR ALL ROOF PITCHES IN EXTRA HIGH WIND ZONES.
- 4 **EXCLUDES DRIP FDGE**
- INTERNAL GUTTER SHOULD BE MADE FROM NONFERROUS METAL 5. COMPATIBLE WITH THE ROOFING MATERIAL
- GUTTER SHALL BE SIZED TO SUIT THE ROOF CATCHMENT AREA BUT SHALL BE NO LESS THAN THAN SHOWN IN THIS FIGURE AND DESIGNED IN ACCORDANCE WITH E2/AS I AND/OR THE NZ METAL ROOF \$ WALL CLADDING CODE OF PRACTICE.

(6)	
X mın	
45	
20	

SITE WIND ZONE	MINIMUM	
(As per NZ53604)	Z	
SITUATION I (1)	50 ⁽⁴⁾	
SITUATION 2 (2)	75 ⁽⁴⁾	
SITUATION 3 (3)	90 (4)	

NOTES:

BARGE CAPPING

SCREW FIXING

FASCIA

BOARD

FLYING RAFTFR

PRE-PRIMED

METAL RAKING GUTTER

- These details are generally in compliance with E2/AS I and/or the NZ Metal Roof \$ Wall Cladding Code of Practice and in some cases specific details by 'Roofing
- The building designer is ultimatley responsible to ensure that details used meet the requirements of the NZ Building Code for the specific project.
- Details of the supporting structure including cavity battens are indicative only and are the responsibility of the building designer. For steel framed buildings thermal break

BLOCKING PIECES

- Underlay selection and building wrap types are the responsibility of the designer, Netting or other support is generally required at roof pitches less than 8 degrees combined with a self supporting paper. At roof pitches of 8° and above where non self supporting paper is used or purlin spacing is in excess of self supporting criteria, netting or other support should be used. Alternative support to netting should be used in severe coastal environments including when aluminium is used.
- These details are for Roofing Industries profile/s as nominated and may not be applicable to other profiles.
- This drawing is the copyright of 'Roofing Industries' and can only be copied or reproduced with their permission.

TIMBERTEK & NEO WITH 25mm ALLOY EMBOSSED

WASHERS

- These details to be read with Roofing Industries profile technical summary regarding wind loads and fixings.
- Further information can be obtained from the NZ Metal Roof \$ Wall Cladding Code of Practice: www.metalroofing.org.nz OR NZBC clause E2/AS I.

Copyright detail

