



Building underlay over Apron flashing

Ultraclad® UA 7868 weatherboards fixed with Locator Clips fixed at Max 600 mm vertical centres with 8g x 2" CSK Sq S/S self tapping screws through batten into dwang / nog

Ultraclad® Cavity Vent Strip
Alternatively use PVC type

Note: Underlay strips to isolate aluminium from treated timber battens.
Refer V00

Cavity batten
Refer V00 Batten Options

Ultraclad® UA 4863 Vertical Starter. 5 mm diameter drainage hole drilled through base of Vertical Starter at 300 mm centres

Apron flashing with 75 mm up stand cover behind cladding

Turn-down to suit roofing profile

Note: Ensure to alternate spacings of fixings for battens and Locator Clips to avoid risk of splitting batten

Nog as required

75 mm MIN cover above bottom of weatherboard

110 MIN Total

Flashing length
See Table 7 E2/AS1

Roofing underlay turned up under flashing

Selected roofing with stop ends

