RESIDENTIAL TRIMRIB® WALL CLADDING HEAD FLASHING FOR VERTICAL CLADDING ON CAVITY (RECESSED WINDOW/DOOR)

CAVITY BATTEN ROOFING INDUSTRIES 'TRIMRIB' SCREW FIXING ADDITIONAL BUILDING WRAP FROM OVERLAP ABOVE OR TOP OF WALL LAPPED OVER FLASHING OR USE WINDOW FLASHING TAPE BUILDING WRAP DRESSED INTO OPENING WITH 50mm RETURN TO INSIDE OF FRAME WITH WINDOW FLASHING TAPE INSTALLED OVER WRAP TO CORNERS 15mm min. COVER ROOFING INDUSTRIES HEAD FLASHING WITH 15° FALL AIR SEAL WITH STOP ENDS **PACKERS** WINDOW FRAME

(Dimensions are indicative only)

Turn down end of head
flashing to jamb flashing

Detail Number: RI-RTWO | 2A-1

Date drawn: 07/07/2017

Scale: 1:5@ A4

GENERAL NOTES:

- . REFER TO E2/AS I FOR GENERAL WINDOW OPENING FOR WRAPPING OF FRAMED OPENING PRIOR TO WINDOW INSTALLATION
- 2. A MIN, OF 8mm EFFECTIVE COVER AT SILLS SHALL BE PERMITTED WHERE NECESSARY TO ALLOW FOR TOLFRANCES
- 3. WINDOW PROFILE TO BE SELECTED TO ACHIEVE COVER SHOWN IN DETAILS.
- 4. ARCHITRAVE'S ARE SHOWN FOR CONSISTENCY ONLY, DETAIL MAY BE USED WITH REBATED LINER.
- 5. WHERE SUPPORT BRACKETS ARE REQUIRED BY THE WINDOW MANUFACTURER TO CARRY THE FRAME AND GLAZING LOADS THEY MUST BE SUPPLIED AS AN INTEGRAL PART OF THE WINDOW MANUFACTURER'S RECOMMENDATIONS.
- LIASE WITH WINDOW MANUFACTURER PRIOR TO INSTALLATION.
- 7. SEAL HEAD FLASHING TO WINDOW IN VERY HIGH ¢ EXTRA HIGH WIND ZONES.
- 8. REFER TO E2/AS I FOR ALTERNATIVE.
- CAVITY BATTENS CONTAINING CORROSIVE MATERIAL MUST BE SEPARATED FROM METAL CLADDING BY DPC, BUILDING WRAP, PVC OR PAINTING
- IO. CASTELLATED BATTEN, DRAINAGE PLASTIC BATTEN OR APPROVED DRAINED BATTEN CAN BE USED WITH THIS SYSTEM

NOTES:

- These details are generally in compliance with E2/AS I and/or the NZ Metal Roof \$ Wall Cladding Code of Practice and in some cases specific details by 'Roofing Industries'.
- The building designer is ultimatley responsible to ensure that details used meet the requirements of the NZ Building
 Code for the specific project.
- Details of the supporting structure including cavity battens are indicative only and are the responsibility of the building designer. For steel framed buildings thermal break cavity battens may be required.
- Underlay selection and building wrap types are the responsibility of the designer. When rigid wall underlay is
 required it is the designers responsibility to ensure the correct type is used and follow the manufacturers
 recommendation for installation.
- These details are for Roofing Industries profile/s as nominated and may not be applicable to other profiles.
- This drawing is the copyright of 'Roofing Industries' and can only be copied or reproduced with their permission.
- Further information can be obtained from the NZ Metal Roof \$ Wall Cladding Code of Practice: www.metalroofing.org.nz OR NZBC clause E2/AS I.

REFERENCE FLASHINGS:
NZ METAL ROOF AND WALL
CLADDING CODE OF PRACTICE
NZMRM AND E2/AS I.
DIMENSIONS ARE INDICATIVE ONLY

