

Substrate Checklist : Concrete

- Ensure concrete substrate has been allowed to fully cure - at least 28 days from pour.
- If the concrete is less than 28 days old and a concrete surface sealer has been used or a rapid curing compound, you must identify the product and verify correct curing has taken place prior to laying.
- Relative humidity of concrete substrates must be 75% or less before application. (This can be verified with the use of a hygrometer).
- Fill hollows or holes with a cement plaster.
- Surface to leave smooth, clean, dry and free of debris or release agents.
- Venting installed as required. Contact Viking Roofspec if a venting specification has not been provided.
- Use minimum 50mm bond-breaker tapes over expansion joints.
- Minimum 20mm triangular fillets are the base of the upstands for Bituclad, Butylclad and Epiclاد. (Not Enviroclad or Dec-K-ing).
- All drains and outlets are membrane compatible.
- Minimum required falls are met. E2/AS1 2011 states 2° for roofs (~ 1:30) 1.5° for decks (~1:40); 1:100 for internal gutters.
- Please ensure you have ordered the correct membrane, colour and thickness for your project.

Notes:

- Please ensure you have clearly ordered the correct membrane, colour and thickness for your project.
- Correct substrate installation is critical to durability and performance of the membrane. Failure to strictly comply with substrate specification may result affect the product warranty.
- All constructions should comply with the New Zealand Building Code. Contact your local council for further advice.
- Communication between the Applicator and Construction Company will assist to ensure this specification is met.

Information regarding our products, specifications and warranties is available at www.vikingroofspec.co.nz
If you have a query regarding this substrate specification please call Viking on **0800 729 799**.

Auckland Office
80 Alexander Crescent, Otara
P.O. Box 14-541, Panmure
Auckland 1741, New Zealand

Christchurch Office
2 Nazareth Avenue, Middleton
P.O. Box 9117, Tower Junction
Christchurch 8149, New Zealand

T: 0800 729 799
F: 0800 729 788
info@[vikingroofspec.co.nz](mailto:info@vikingroofspec.co.nz)
www.vikingroofspec.co.nz

Roofspec
Viking
Taking care of detail