

Alternative support to galvanised netting should be used in severe coastal environments

Thermal break or cavity battens may be required in some circumstances. Underlay selection and building wrap types are the responsibility of the designer,

TYPICAL BARGE (Notched)

including when aluminium is used.

to other profiles.

These details are for Roofing Industries profile/s as nominated and may not be applicable

This drawing is the copyright of 'Roofing Industries' and can only be copied or

reproduced with their permission.

Practice www.metalroofer.org.nz & www.roof.co.nz

Further information can be obtained from the NZ Metal Roof & Wall Cladding Code of

roof.co.nz

Details are for steel based materials, other substrate may require some changes

Where necessary adjust drawings for purlin battens or cavity battens