

©COPYRIGHT DETAIL 2012



Further information can be obtained from the NZ Metal Roof & Wall Cladding Code of Practice www.metalroofer.org.nz & www.roof.co.nz
Where necessary adjust drawings for purlin battens or cavity battens.

reproduced with their permission.

applicable to other profiles.

environments including when aluminium is used.

Underlay selection and building wrap types are the responsibility of the designer, Alternative support to galvanised netting should be used in severe coastal

Thermal break or cavity battens may be required in some circumstances

This drawing is the copyright of 'Roofing Industries' and can only be copied or

These details are for Roofing Industries profile/s as nominated and may not be

of the building designer.

Details of the supporting structure are indicative only and are the responsibility

the requirements of the NZ Building Code for the specific project

The building designer is ultimately responsible to ensure that details used meet

Details are for steel based materials, other substrate may require some changes