PENETRATION FLASHING WATERSHED TO UNDER RIDGE SEAL & RIVE COVER FLASKI COMMERCIAL MULTIRIB ROOFING NO MILIT -TURN DOWN INTO TROUGH _NOTCHED TURN-DOWN OVER RIBS -HEM OVER RIBS NOTCHED TURN-DOWN ROOFING INDUSTRIES MULTIRIB OF BACK FLASHING TURN UP BOTTOM EDGE FLOW OR CRICKET FLASHING BACK FLASHING SCREW TO PURLIN SEAL AND FASTEN AS PER NZMR#WCCOF RIDGE / APRON DATE DRAWN DETAIL NO. FILE REFERENCE (2) REFER TO SECTION 6 OF NZMRM CODE OF PRACTICE FOR (1) ADDITIONAL SUPPORT FRAMING MAYBE REQUIRED WHEN CATCHMENT AREA LIMITATIONS. PENETRATION EXCEEDS 200mm THROUGH ROOF RI-CMRRO I & A. DWG 01/03/12 CMRRO I 8A

©COPYRIGHT DETAIL 2012

NOTES:

These details are generally in compliance with the NZ Metail Roof & Wall Cladding Code of Practice and in some cases specific details by 'Roofing Industries'.

The building designer is ultimately responsible to ensure that details used meet

the requirements of the NZ Building Code for the specific project.

Details of the supporting structure are indicative only and are the responsibility of

the building designer.

reproduced with their permission.

applicable to other profiles

of Practice www.metalroofer.org.nz & www.roof.co.nz

Where necessary adjust drawings for purlin battens or cavity battens.

Details are for steel based materials, other substrate may require some changes

Further information can be obtained from the NZ Metal Roof & Wall Cladding Code

These details are for Roofing Industries profile/s as nominated and may not be

This drawing is the copyright of 'Roofing Industries' and can only be copied or

environments including when aluminium is used.

Alternative support to galvanised netting should be used in severe coastal

Thermal break or cavity battens may be required in some circumstances. Underlay selection and building wrap types are the responsibility of the designer,

