



NOTE

- CLEAN & VACUUM ANY WATER & DEBRIS FROM THE SPEEDFLOOR FLOOR JOIST THROUGH
- ENSURE NO POOLING WATER IS LEFT ON CEILING PANEL ALLOW
- ALLOW FOR SWAGING OF SPEEDFLOOR FLOOR JOISTS TO CLEAR CEILING STRAP