



- Note:
- This detail is only relevant to a standard post rather than cantilevered post
 - For corner post use 4-3/16 ss rivets (2 rivets each side)

Stainless steel M10 bolt. Grease the underside of the bolt head and top 10mm section of the shaft before installing

Scale: 1 : 5

Disclaimer: This information is intended solely as a guide for use of Johnson and Couzins Ltd products. Before using these product you should ensure that the product is suitable for use in the specific application. Nothing in this information constitutes a statement of fitness for particular purpose - appropriate expert advice should always be obtained. Johnson and Couzins Ltd makes no warranty regarding the use of this information with non-Johnson and Couzins Ltd product. © 2019 . The copyright of this document is the property of Johnson and Couzins Ltd and shall not be reproduced, copied, loaned or disposed of directly, or indirectly, nor used for any purpose other than that for which it is specifically furnished without prior consent.

Technical Help 0800 664 083

JAC_CR_6019

www.johnsonandcouzins.com