



SPEEDFLOOR

Faster Lighter Easier

Serviceable Life

The rollformed joist is manufactured from steel coated with either 275g/sqm of zinc. If the joists are in a clean and dry environment they will require little or no maintenance. If they are exposed, they will require a minimum amount of maintenance to ensure the expected performance is achieved. Guidelines for this maintenance are:

1. Keep surfaces clean and free from continuous contact with moisture, dust and other debris (a 14 MPa waterblast every 2 years will suffice).
2. Periodically inspect the joists for any signs of surface corrosion. Remove any by-products of the corrosion by mechanical means and spot prime the exposed steel substrate with an approved steel primer. Repaint the area using an appropriate paint to manufacturer's recommendations.

Storage and Handling

Bundles of Speedfloor joist should be kept dry during transport. Following transport, bundles should be covered and stored off the ground on dunnage at a slight angle to avoid water or condensation from being trapped between the surfaces.

If bundles become wet, beams should be separated as soon as possible, wiped clean and placed apart to allow air circulation.

Avoid sliding beams over rough surfaces or each other.