



Add the above amounts to the desired floor size to work out the "finished" inside size of your lift shaft. i.e. A 1000mm floor with a door opposite the cylinder will require a 1260mm deep shaft

