

## 7000/9000 and Medio Series Installation Instructions 6000/8000 and Series Installation Instructions

WARNING: Accurate door preparation is essential for the functioning of this lock. Please follow the enclosed template and instructions carefully.

NOTE:

Wood screw fixing is optional. Through bolt fixing is recommended.







Reference: ZPIC

