
PRODUCT OVERVIEW LOUVRETEC OUTDOOR BLINDS GENERAL AND MAINTENANCE

treat with care


- Avoid using abrasive cleaning agents such as Ajax, jif or steel wool in any circumstances.
- Ensure the blind is fully up when you are away from your home or in extreme weather conditions.
- Avoid rolling up when wet moisture within the roll may cause mould and mildew. Always allow to dry before retracting.
- If the blind is jamming, please treat with care. Forcing may result
 in further damage such as the zip being forced out of the side
 channel or the fabric ripping. Contact your supplier for guidelines
 of how to fix it.
- Spring controlled Louvretec blinds should only be operated from the middle – always use the weight bar or handle and pull from the centre.







MESH SHADE BLIND SHOWING MINOR SURFACE DIFFERENCES



WARRANTY DETAILS

All outdoor blinds installed by Louvretec, or an Authorised Louvretec installer are from date of invoice, fully warranted for the first year. Mesh blind skins are also covered by a five year manufacturers warranty.

Due to the unstable nature of PVC, there is no manufacturer's warranty available on the PVC skin itself.

This warranty covers workmanship, and all componentry, motors, switches and electronics with all labour costs included. In addition, from year two to end of year five, a warranty replacement of parts only applies for all motors, switches and electronics. Labour costs excluded (excludes any wiring and electrical connections done by others).

Spare parts and repairs are available from your Louvretec Dealership. Only Louvretec approved spare parts are to be used.