



Ulltraclad® UA 4533 Head Starter

**IMPORTANT:**  
 Sizes shown are indicative only!  
 Contractor to confirm onsite as  
 joinery suites may vary.

Applying sealant before fitting UA 4533  
 sealant at facade

Note: Ulltraclad® UA 4533 Head Starter to extend  
 40 mm past edge of window or door joinery.  
 Building underlay, flashing tape and UA 5833  
 omitted for clarity

Ulltraclad® UA 4533 Head Starter 5 mm diameter drainage  
 holes drilled through base of Head Starter at 300 mm centres

Ulltraclad® UA 7584 Jamb Flashing