



Ulltraclad© UA 4533 Head Starter 5 mm diameter drainage holes drilled through base of Head Starter at 300 mm centres

Ulltraclad© UA 4533 Head Starter

**IMPORTANT:**  
 Sizes shown are indicative only!  
 Contractor to confirm onsite as  
 joinery suites may vary.

Applying sealant before fitting UA 4533 sealant at facade

Note: Ulltraclad© UA 4533 Head Starter to extend 40 mm past edge of window or door joinery. Building underlay, flashing tape and UA 5833 omitted for clarity

Ulltraclad© UA 7584 Jamb Flashing