

## **Product Care and Maintenance**

Kilargo Pty Ltd recommends that its seals are installed in accordance with the installation instructions provided.

To ensure correct operation, seals are to be inspected at regular intervals and adjusted in accordance with the provided instructions. Worn or damaged seals should be replaced to maintain optimum sealing performance.

We recommend cleaning at periodic intervals, using warm water mixed with mild detergent and wiping lightly with a soft cloth or sponge. Harsh chemicals and solvents should always be avoided as they could damage the seals.

**Kilargo Pty Ltd**