## RESIDENTIAL TRIMRIB® WALL CLADDING SLOPING SOFFIT FLASHING FOR VERTICAL TRIMRIB ON CAVITY

NOTCHED TURN DOWN OR SOFT FDGF STOPFNDS AND CONTINUOUS COMPRESSABLE FOAM SEAL SILICONE OR MS POLYMER SEALANT FASCIA BD **EAVE SOFFIT** SOFFIT FLASHING WITH CRUSH **♯ FOLD TO LOWER EDGE** BLIND RIVET FIXED TO CLADDING ROOFING INDUSTRIES TRIMRIB' BUILDING WRAP **CAVITY BATTEN** 

## NOTES:

- These details are generally in compliance with E2/AS I and/or the NZ Metal Roof \$ Wall Cladding Code of Practice and in some cases specific details by 'Roofing Industries'.
- The building designer is ultimatley responsible to ensure that details used meet the requirements of the NZ Building Code for the specific project.
- Details of the supporting structure including cavity batters are indicative only and are the responsibility of the building designer. For steel framed buildings thermal break cavity batters may be required.
- Underlay selection and building wrap types are the responsibility of the designer. When rigid wall underlay is
  required it is the designers responsibility to ensure the correct type is used and follow the manufacturers
  recommendation for installation.
- These details are for Roofing Industries profile/s as nominated and may not be applicable to other profiles.
- This drawing is the copyright of 'Roofing Industries' and can only be copied or reproduced with their permission.
- Further information can be obtained from the NZ Metal Roof \$ Wall Cladding Code of Practice: www.metalroofing.org.nz OR NZBC clause E2/AS I.

Detail Number: RI-RTW007A-I

Date drawn: 07/07/2017

Scale: 1:5@ A4

## NOTES:

- I. CAVITY BATTENS CONTAINING CORROSIVE
  MATERIAL MUST BE SEPARATED FROM
  METAL CLADDING BY DPC, BUILDING WRAP,
  PVC OR PAINTING
- 2. CASTELLATED BATTEN, DRAINAGE PLASTIC
  BATTEN OR APPROVED DRAINED BATTEN
  CAN BE USED WITH THIS SYSTEM







