## RESIDENTIAL RIBLINE® WALL CLADDING EXTERNAL CORNER FOR VERTICAL CLADDING ON CAVITY WITH CLADDING CHANGE

ROOFING INDUSTRIES RIBLINE' HORIZ BATTEN BETWEEN VERTICAL BATTENS BUILDING WRAP CONTINUOUS AROUND CORNER FLASHING RIVET FIXED TO CLADDING PAN SCREW FIXING EXTERNAL CORNER FLASHING TO COVER MINIMUM OF 2 CREST AND FINISH PLYWOOD, FIBROUS CEMENT 2-5mm GAP FROM PAN OF CLADDING OR SHEET CLADDING LAP SFAL TAPE OR SFALANT SEPARATION OF BATTEN AND METAL CLADDING 80

Detail Number: RI-RRW003B-I

Date drawn: 07/07/2017

Scale: 1:5@ A4

## NOTES:

- I. CAVITY BATTENS CONTAINING CORROSIVE
  MATERIAL MUST BE SEPERATED FROM METAL
  CLADDING BY DPC, BUILDING WRAP, PVC OR
  PAINTING
- 2. CASTELLATED BATTEN, DRAINAGE PLASTIC
  BATTEN OR APPROVED DRAINED BATTEN CAN
  BE USED WITH THIS SYSTEM

NOTES:

- These details are generally in compliance with E2/AS I and/or the NZ Metal Roof \$ Wall Cladding Code of Practice and in some cases specific details by 'Roofing Industries'.
- The building designer is ultimatley responsible to ensure that details used meet the requirements of the NZ Building Code for the specific project.
- Details of the supporting structure including cavity batters are indicative only and are the responsibility of the building designer. For steel framed buildings thermal break cavity batters may be required.
- Underlay selection and building wrap types are the responsibility of the designer. When rigid wall underlay is required it is the designers responsibility to ensure the correct type is used and follow the manufacturers recommendation for installation.
- These details are for Roofing Industries profile/s as nominated and may not be applicable to other profiles.
- This drawing is the copyright of 'Roofing Industries' and can only be copied or reproduced with their permission.
- Further information can be obtained from the NZ Metal Roof \$ Wall Cladding Code of Practice: www.metalroofing.org.nz OR NZBC clause E2/AS I.





