



**KEY**

- Framing
- Batten
- Corner Batten
- Vertical Track Flashing

**Batten options**

Impervious barrier ( MDPE ) or similar tape between cladding and batten.  
 To comply with NZBC E2/AS1 - Table 23.  
 Note:  
 Some machining of battens may be required to avoid "build up".  
 i.e. back flashings / tapes

Cavity plastic Batten  
 Note:  
 packing/shims may be needed to ensure boards are fitted flat without distortion.

\* Additional timber may be required at soffit to support UA 5831 Soffit Base.

**Note: Important**

Underlay strips to isolate aluminium from treated timber battens 50 mm wide medium density polyethylene ( MDPE )

To comply with NZBC E2/AS1 - Table 23. Properties of roofing underlays and wall underlays, separates aluminium components and accessories from timber battens treated with copper-based treatments

Cavity closers required as per NZBC E2/AS1 (section 9.1.8)

Vertical Cavity Corner Batten  
 50 x 25 mm H3.1 treated Radiata. Cavity battens fixed with 6g x 1.25" CSK Sq S/S pre-drilled screws through batten into stud

0.9 x 90 mm Aluminium Track Flashing. Alternatively use Dynex Dynafash.