## RESIDENTIAL SLIMLINE CORRUGATE WALL CLADDING VERTICAL CLADDING ON CAVITY JUNCTION FLASHING

Detail Number: RI-RSLWO I OA-I

Date drawn: 07/07/2017

Scale: 1:5@ A4

	ROOFING INDUSTRIES 'SLIMLINE MINI CORRUGATE'	<b> </b>
	HORIZ BATTEN BETWEEN	
	VERTICAL BATTENS	
	SCREW FIXING IN TROUGH	
	SEPERATION OF CLADDING ANDBATTEN	
	BUILDING WRAP FROM ABOVE	Z   BUILDING WRAP
	LAPPED OVER FLASHING	\ \   \_ \   \   \
		¥ ° † † †
	5140111110	LS DPC
	FLASHING    WITH 10° FALL	
Bırd's beak dımensıons may vary	2.trt	5mm min.
between manufacturing		
manuracturing	BIRD'S BEAK at bottom	

SITE WIND ZONE	MINIMUM		
(As per NZS3604)	Z	Y	
SITUATION I (1)	75mm	75mm <sup>(3)</sup>	
SITUATION 2 (2)	I OOmm	I OOmm <sup>(3)</sup>	

## NOTES:

- SITUATION 1: IN LOW, MEDIUM OR HIGH WIND ZONES.
- 2. SITUATION 2: FOR VERY HIGH \$ EXTRA HIGH WIND ZONES.
- EXCLUDES DRIP EDGE.
- 4. CAVITY BATTENS CONTAINING CORROSIVE MATERIAL MUST BE SEPARATED FROM METAL CLADDING BY DPC, BUILDING WRAP, PVC OR PAINTING
- 5. CASTELLATED BATTEN, DRAINAGE PLASTIC
  BATTEN OR APPROVED DRAINED BATTEN CAN
  BE USED WITH THIS SYSTEM

## NOTES:

locations

- These details are generally in compliance with E2/AS I and/or the NZ Metal Roof \$ Wall Cladding Code of Practice and in some cases specific details by 'Roofing Industries'.
- The building designer is ultimatley responsible to ensure that details used meet the requirements of the NZ Building Code for the specific project.
- Details of the supporting structure including cavity batters are indicative only and are the responsibility of the building designer. For steel framed buildings thermal break cavity batters may be required.
- Underlay selection and building wrap types are the responsibility of the designer. When rigid wall underlay is
  required it is the designers responsibility to ensure the correct type is used and follow the manufacturers
  recommendation for installation.
- These details are for Roofing Industries profile/s as nominated and may not be applicable to other profiles.
- This drawing is the copyright of 'Roofing Industries' and can only be copied or reproduced with their permission.
- Further information can be obtained from the NZ Metal Roof & Wall Cladding Code of Practice: www.metalroofing.org.nz or E2/ASI.

edge of vertical flashing

SLIMLINE IS OUTSIDE THE SCOPE OF E2/AS1 BUT MAYBE APPLICABLE FOR NON RESIDENTIAL BUILDINGS OR AS AN ALTERNATIVE SOLUTION

