
## RESIDENTIAL MULTIDEK WALL CLADDING HEAD FLASHING FOR HORIZONTAL CLADDING (RECESSED WINDOW/DOOR)

-ROOFING INDUSTRIES 'MULTIDEK' ADDITIONAL BUILDING WRAP FROM OVERLAP ABOVE OR TOP OF WALL LAPPED OVER CAVITY CLOSER MULTIDEK CLIP SCREW FIXED OR USE WINDOW FLASHING TAPE SEPARATION OF METAL WANZ WIZ CAVITY CLADDING AND BATTEN CLOSER POSITIONED TO GIVE 15mm MIN DRIP STOP FND TO HEAD FLASHING EDGE TO CLADDING BEHIND CLADDING BUILDING WRAP DRESSED INTO OPENING WITH 50mm RETURN TO INSIDE OF FRAME WITH WINDOW FLASHING TAPE INSTALLED OVER WRAP TO CORNERS 20 ROOFING INDUSTRIES AIR SFAI HEAD FLASHING WITH 15° FALL **PACKERS** WINDOW FRAME



(Dimensions are indicative only)
Turn down end of head flashing to
jamb flashing.

At end of head flashing under sheet may need flattening or carefully slit and seal. Detail Number: RI-RMDW032A

Date drawn: 07/07/2017

Scale: 1:5@ A4

## GENERAL NOTES:

- I. REFER TO E2/AS I FOR GENERAL WINDOW OPENING FOR WRAPPING OF FRAMED OPENING PRIOR TO WINDOW INSTALLATION.
- A MIN. OF 8mm EFFECTIVE COVER AT SILLS SHALL BE PERMITTED WHERE NECESSARY TO ALLOW FOR TOLERANCES.
- 3. WINDOW PROFILE TO BE SELECTED TO ACHIEVE COVER SHOWN IN DETAILS.
- 4. ARCHITRAVE'S ARE SHOWN FOR CONSISTENCY ONLY,
  DETAIL MAY BE USED WITH REBATED LINER.
- 5. WHERE SUPPORT BRACKETS ARE REQUIRED BY THE WINDOW MANUFACTURER TO CARRY THE FRAME AND GLAZING LOADS THEY MUST BE SUPPLIED AS AN INTEGRAL PART OF THE WINDOW MANUFACTURER'S RECOMMENDATIONS.
- LIAISE WITH WINDOW MANUFACTURER PRIOR TO INSTALLATION.
- 7. SEAL HEAD FLASHING TO WINDOW IN VERY HIGH & EXTRA HIGH WIND ZONES.

REFERENCE FLASHINGS:

NZ METAL ROOF AND WALL CLADDING

CODE OF PRACTICE AND E2/AS I.

DIMENSIONS ARE INDICATIVE ONLY.

## NOTES:

- These details are generally in compliance with E2/AS I and/or the NZ Metal Roof \$ Wall Cladding Code of Practice and in some cases specific details by 'Roofing Industries'.
- The building designer is ultimatley responsible to ensure that details used meet the requirements of the NZ Building Code for the specific project.
- Details of the supporting structure including cavity batters are indicative only and are the responsibility of the building designer. For steel framed buildings thermal break cavity batters may be required.
- Underlay selection and building wrap types are the responsibility of the designer. When rigid wall underlay is
  required it is the designers responsibility to ensure the correct type is used and follow the manufacturers
  recommendation for installation.
- These details are for Roofing Industries profile/s as nominated and may not be applicable to other profiles.
- This drawing is the copyright of 'Roofing Industries' and can only be copied or reproduced with their permission.
- Further information can be obtained from the NZ Metal Roof \$ Wall Cladding Code of Practice: www.metalroofing.org.nz OR NZBC clause E2/AS I.





