COMMERCIAL CORRUGATE WALL CLADDING WINDOW / DOOR HEAD FLASHING - VERTICAL CLADDING

ROOFING INDUSTRIES CORRUGATE SCREW FIXING THROUGH PAN OR CREST ADDITIONAL BUILDING WRAP FROM OVERLAP ABOVE OR TOP OF WALL LAPPED OVER FLASHING **BUILDING WRAP DRESSED** OR USE WINDOW FLASHING TAPE INTO OPENING WITH 50mm RETURN TO INSIDE OF FRAME WITH WINDOW min. cover 60 mm FLASHING TAPE INSTALLED **OVER WRAP TO CORNERS** 15mm min. COVER **ROOFING INDUSTRIES** AIR SEAL HEAD FLASHING WITH 15° FALL **PACKERS WINDOW FRAME**

10 65

10

(Dimensions are indicative only) Turn down end of head flashing to jamb flashing

/15° 50 min

GENERAL NOTES:

REFER TO E2/AS1 FOR GENERAL WINDOW OPENING FOR WRAPPING OF FRAMED OPENING PRIOR TO WINDOW INSTALLATION.

Detail Number: RI-CCW012A

Date drawn: 01/08/2019


Scale: 1:5@ A4

- A MIN. OF 8mm EFFECTIVE COVER AT SILLS SHALL BE PERMITTED WHERE NECESSARY TO ALLOW FOR TOLERANCES.
- WINDOW PROFILE TO BE SELECTED TO ACHIEVE COVER SHOWN IN DETAILS.
- WHERE SUPPORT BRACKETS ARE REQUIRED BY THE WINDOW MANUFACTURER TO CARRY THE FRAME AND GLAZING LOADS THEY MUST BE SUPPLIED AS AN INTEGRAL PART OF THE WINDOW MANUFACTURER'S RECOMMENDATIONS.
- LIASE WITH WINDOW MANUFACTURER PRIOR TO INSTALLATION.
- 6. SEAL HEAD FLASHING TO WINDOW IN VERY HIGH & EXTRA HIGH WIND ZONES.
- 7. REFER TO E2/AS1 FOR ALTERNATIVE.
- IF UNDERLAY USED AS A VAPOUR BARRIER IT MAY REQUIRE A 20mm MIN AIR GAP BETWEEN THE UNDERSIDE OF THE ROOFING & UNDERLAY.

REFERENCE FLASHINGS: NZ METAL ROOF AND WALL CLADDING CODE OF PRACTICE NZMRM AND E2/AS1. DIMENSIONS ARE INDICATIVE ONLY

Copyright detail (C)







NOTES:

- These details are generally in compliance with E2/AS1, where applicable to profile, and the NZ Metal Roof & Wall Cladding Code of Practice and in some cases specific details by 'Roofing Industries'.
- The building designer is ultimately responsible to ensure that details used meet the requirements of the NZ Building Code for the specific project.
- Details of the supporting structure are indicative only and are the responsibility of the building designer.
- Thermal break or cavity battens may be required in some circumstances.
- Underlay selection and building wrap types are the responsibility of the designer. Alternative support to galvanised netting should be used in severe coastal environments including when aluminium is used.
- These details are for Roofing Industries profile/s as nominated and may not be applicable to other profiles.
- This drawing is the copyright of 'Roofing Industries' and can only be copied or reproduced with their permission.
- Further information can be obtained from the NZ Metal Roof & Wall Cladding Code of Practice: www.metalroofing.org.nz or E2/AS1.
- Where necessary, adjust drawings for purlin or cavity battens.
- Details are for steel based materials, other substrate may require some changes.