Detail No. RI-RTDRO | GC RESIDENTIAL TRUE OAK® DEEP CORRUGATE Date drawn: 01/02/2020 ROOFING Scale: 1:5@ A4 CHIMNEY FLASHING, MID ROOF Version: 01 MAX ROOF LENGTH NOTE: USE BACK FLASHING TO RIDGE WHERE POSSIBLE. CATCHMENT SEPERATE ROOFING SHEET/S ABOVE PENETRATION WIDTH TRIM TO FORM TWO OVERLAPS 0-400 12 METRES 400-600 8 METRES CHIMNEY CUT 600-800 6 METRES AWAY FOR 800-1200 4 MFTRES FLOW OR CRICKET FLASHING CLARITY AS PER NZMR≢WCCOP MIN mm (cover) SITE WIND ZONE HEM (As per NZS3604) Х Y COVER VENT PERF TO SUIT PROFILE FLASHING SITUATION I (1) 150 2 CRESTS ROOFING INDUSTRIES 'TRUE SITUATION 2 (2) 200 2 CRESTS OAK' DEEP CORRUGATE BACK FLASHING NOTES: SEAL & RIVET 1. SITUATION 1: IN LOW, MEDIUM OR HIGH WIND ZONES. WHERE ROOF PITCH IS 10° OR GREATER. SIDE FLASHING 2 SITUATION 2: FOR ALL ROOF PITCHES IN VERY HIGH # EXTRA HIGH WIND ZONES, FOR ALL LESSOR WIND LAYING SEQUENCE: ZONES WHERE ROOF PITCH LESS THAN 10°. A. SOFTEDGE APRON. FLASHING SOFT EDGE 3. ALSO REFER TO NZ METAL ROOF & CLADDING CODE B. SIDE FLASHING, DRESSED INTO PROFILE -C. BACK FLASHING. OF PRACTICE.

D. COVER FLASHING (CHASED) 4.

- NOTES:
- These details are generally in compliance with E2/AS1 and/or the NZ Metal Roof & Wall Cladding Code of Practice and in some cases specific details by 'Roofing Industries'.
- The building designer is ultimatley responsible to ensure that details used meet the requirements of the NZ Building Code for the specific project.
 Details of the supporting structure including cavity battens are indicative only and are the responsibility of the building designer. For steel framed buildings thermal break cavity battens may be required.
- Underlay selection and building wrap types are the responsibility of the designer, Netting or other support is generally required at roof pitches less
 than 8 degrees combined with a self supporting paper. At roof pitches of 8° and above where non self supporting paper is used or purlin spacing
 is in excess of self supporting criteria, netting or other support should be used. Alternative support to netting should be used in severe coastal
 environments including when aluminium is used.
- These details are for Roofing Industries profile/s as nominated and may not be applicable to other profiles.
- This drawing is the copyright of 'Roofing Industries' and can only be copied or reproduced with their permission.
- These details to be read with Roofing Industries profile technical summary regarding wind loads and fixings.
- Further information can be obtained from the NZ Metal Roof & Wall Cladding Code of Practice: www.metalroofing.org.nz or E2/AS1. Underlay selection and building wrap types are the responsibility of the designer, Netting or other support is generally required at roof pitches less than 8 degrees combined with a self supporting paper.



SUITABLE FOR ROOF PITCHES OF 10° OR HIGHER